

Kelsy



620 Kelsy Dining
Side Chair
 $18 \times 25 \times 40$



621 Kelsy Balcony
Side Chair
 $18 \times 25 \times 36$



622 Kelsy Pub
Side Chair
 $18 \times 25 \times 52$



623 Kelsy Dining
Arm Chair
 $25 \times 25 \times 40$



624 Kelsy Balcony
Arm Chair
 $25 \times 25 \times 46$



625 Kelsy Pub
Arm Chair
 $25 \times 25 \times 52$



626 Kelsy Dining
Swivel Arm Chair
 $25 \times 25 \times 40$



627 Kelsy Balcony
Swivel Arm Chair
 $25 \times 25 \times 46$



628 Kelsy Pub Swivel
Arm Chair
 $25 \times 25 \times 57$

Wave



690 Wave Dining
Side Chair
 $25 \times 25 \times 40$



691 Wave Balcony
Side Chair
 $25 \times 25 \times 46$



692 Wave Pub
Side Chair
 $25 \times 25 \times 57$



693 Wave Dining
Arm Chair
 $25 \times 25 \times 40$



694 Wave Balcony
Arm Chair
 $25 \times 25 \times 46$



695 Wave Pub
Arm Chair
 $25 \times 25 \times 57$



696 Wave Dining
Swivel Arm Chair
 $25 \times 25 \times 40$



697 Wave Balcony
Swivel Arm Chair
 $25 \times 25 \times 46$



698 Wave Pub
Swivel Arm Chair
 $25 \times 25 \times 57$